PARTS LIST

SSD600

2018.08.

MARUYAMA

P/N 524643


■PRECAUTIONS FOR USING THE PARTS LIST


1. When ordering a part, specify the model name, part number, part name and quantity of the part required.
2. For the retail prices, refer to the price list on the attached sheet.
3. Be sure to use the genuine MARUYAMA parts.
4. There are parts included in the product but not listed in this document.
5. The parts are subject to change for product improvement without prior notice.
6. On the illustration page, there is a sentence, such as "See Fig. xx". This "xx" refers to the heading number shown in the top-left corner of the illustration page.

CONTENTS


1.FRAME, BUMPER 2
2.AXLE 4
3.HITCH, UNDER COVER 6
4.PUMP-1 (MS800S) 8
5.PUMP-2 12
6.DRIVE UNIT 14
7.CHEMICAL TANK 16
8.WASHING TANK 18
9.TANK FRAME 20
10.FAN-1 22
11.FAN-2 24
12.GEAR BOX 26
13.NOZZLE 30
14.STRAINER 34
15.WATER DIVERSION 36
16.CHEMICAL PIPING 38
17.LABEL 40
18.ACCESSORIES 42

1. SSD600
FRAME, BUMPER






DETAIL"B"




DETAIL"A"



DETAIL"C"


Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
1-1	366906	SSD600	1	
1-2	568373	Frame Comp.	1	
1-3	568389	Bracket	1	
1-4	568390	Stay	1	
1-5	568391	Bracket	1	
1-6	568392	Bracket	1	
1-7	194013	Clamp Band	7	
1-8	567065	Flange Bolt	4	M10x25
1-9	567064	Flange Nut	4	M10
1-10	107581	Nylon Nut	8	M8
1-11	127216	Washer	8	M8
1-12	567093	Flange Bolt	8	M8x25
1-13	860533	Bolt	3	M12x30
1-14	567048	Flange Nut	3	M12
1-15	868696	Edge Molding	3	
1-16	568394	Bumper Comp.	1	
1-17	194013	Clamp Band	2	
1-18	860533	Bolt	4	M12x30
1-19	567048	Flange Nut	4	M12
1-20	567093	Flange Bolt	2	M8x25
1-21	107581	Nylon Nut	2	M8
1-22	127216	Washer	2	M8

2. SSD600
AXLE




Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
2-1	568399	Axle Ass'y	1	Incl.2-23
2-2	568400	Axle Bracket Comp.	1	
2-3	568406	Shaft Ass'y	2	Incl.4-18
2-4	568407	Shaft Comp.	2	
2-5	568410	Wheel Hub	2	
2-6	568411	Bearing	2	
2-7	568412	Bearing	2	
2-8	568413	Collar	2	
2-9	056967	C-Sharped Snap Ring	2	#62
2-10	889022	Oil Seal	2	
2-11	568414	Oil Seal	2	
2-12	152862	Sleeve	2	30x35x17L
2-13	568415	Washer	2	19x38xt4.5
2-14	019618	Spring Washer	2	M18
2-15	088458	Nut	2	M18x1.5
2-16	069583	Split Pin	2	4x36L
2-17	057281	Cap	2	
2-18	568416	Hub Bolt	10	M12x1.5x44x34
2-19	080432	Bolt	4	M12x40
2-20	567082	Nut	4	M12
2-21	889189	Bolt	4	M16x35
2-22	688069	Nut	4	M16
2-23	860533	Bolt	4	M12x30
2-24	568417	Tire Ass'y	2	
2-25	568418	Wheel Nut	10	M12x1.5


3. SSD600
HITCH, UNDER COVER



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
3-1	568420	Hitch Comp.	1	
3-2	082545	Bolt	2	M16x100x38
3-3	567139	Washer	2	17x32xt2.6
3-4	683881	U-Nut	2	M16
3-5	568423	Pipe Comp.	1	
3-6	567151	Round Rivet	1	12x92.5L
3-7	567031	Snap Pin	1	12x2.6
3-8	568427	Cover	1	
3-9	568428	Stay	2	
3-10	568429	Cover	1	
3-11	567172	Bolt	8	M6x14
3-12	568430	Bracket Comp.	1	
3-13	567035	Bolt	2	M8x25
3-14	567095	Flange Nut	2	M8


4. SSD600
PUMP-1 (MS800S)






Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
4-1	568434	Pump Ass'y	1	
4-2	151871	Label	1	MS800S
4-3	129985	Crankcase	1	
4-4	044490	Plug	1	R3/8
4-5	086759	Stud Bolt	4	M10x175x20x20
4-6	027488	Spring Pin	2	5x12AW
4-7	091264	Oil Filler Cap Ass'y	1	Incl.8
4-8	014177	O-Ring	1	P35
4-9	129998	Crankcase Cover	1	
4-10	014070	O-Ring	1	S150
4-11	092241	Oil Gauge Ass'y	1	Incl.12
4-12	044428	Packing	1	25x34xt2
4-13	091376	Plug Ass'y	1	G1/4 Incl.14
4-14	023170	O-Ring	1	P12.5
4-15	125824	Bolt	4	M6x16
4-16	660210	Crankshaft	1	
4-17	047080	Bearing	2	#6306
4-18	027930	Oil Seal Case	1	
4-19	027330	Oil Seal	1	D30458
4-20	026965	O-Ring	1	71.7x1.6
4-21	027930	Oil Seal Case	1	
4-22	660216	Seal Cap	1	
4-23	026965	O-Ring	1	71.7x1.6
4-24	125824	Bolt	8	M6x16
4-25	048733	Connecting Rod Ass'y	3	
4-26	120971	Piston Rod Ass'y	3	
4-27	020251	Piston Pin	3	11x29
4-28	126585	Washer	3	24x32xt1.2
4-29	027987	Oil Seal	3	S10.5327
4-30	026853	Packing	3	
4-31	027341	Seal Retainer	3	
4-32	130517	Oil Wick	3	10.5x26x5
4-33	027911	Oil Pan	1	
4-34	100015	Seal Packing	3	
4-35	108383	Inlet Manifold	1	
4-36	100609	Adapter	6	
4-37	026969	O-Ring	12	31.3x2.65
4-38	100610	Packing	1	36x40xt0.5 Only Center
4-39	100615	Cylinder Pipe	3	36x39.5x70
4-40	403947	A Block Ass'y	3	Incl.41-46
4-41	100611	Inlet Valve Seat	3	7x31xt3.8
4-42	412797	Piston Packing	3	Incl.46
4-43	027796	Spacer	3	7x10x11.5
4-44	100614	Piston Retainer	3	
4-45	015850	Spring Washer	3	M7

4. SSD600
PUMP-1 (MS800S)





Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
4-46	115598	Nylon Nut	3	M7
4-47	660214	Discharge Manifold	1	
4-48	100226	Valve Seat	3	
4-49	027952	Valve	3	
4-50	026548	Valve Spring	3	
4-51	027953	Spring Retainer	3	
4-52	100225	Packing	3	27.5x36x0.8
4-53	130548	Air Chamber	1	
4-54	109048	Label	1	
4-55	107405	Plug	1	PT3/4
4-56	058464	Nipple	2	PT3/8xPF3/8
4-57	187159	Ball Cock	1	G3/8xR3/8
4-58	126231	Spring Washer	4	M10
4-59	126522	Nut	4	M10

5. SSD600
PUMP-2





Fig.4


Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
5-1	189175	T-Flange	1	2-G3/4
5-2	682132	Cap	1	G3/4
5-3	187295	Packing	1	26xt3.0
5-4	568651	O-Ring	1	P24
5-5	567035	Bolt	3	M8x25
5-6	568630	Extension (G11/4XG1)	1	
5-7	568435	V-Pulley	1	
5-8	568487	Key	1	7x7x30
5-9	126578	Washer	1	8.5x40xt3.2
5-10	568437	Bracket	1	
5-11	568438	Bracket	1	
5-12	568439	Bracket	1	
5-13	567477	Bolt	1	M10x65
5-14	567143	Nut	1	M10
5-15	567028	Washer	1	10.5x22xt3.2
5-16	080417	Bolt	2	M10x150x30
5-17	567028	Washer	2	10.5x22xt3.2
5-18	126231	Spring Washer	2	M10
5-19	567461	Bolt	4	M10x35
5-20	567064	Flange Nut	4	M10
5-21	568440	Cover Comp.	1	
5-22	567173	Bolt	2	M8x20

6. SSD600
DRIVE UNIT



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
6-1	568483	Shaft	1	
6-2	568484	Bearing Unit	2	
6-3	568485	V-Pulley	1	
6-4	568486	V-Belt	2	
6-5	568487	Key	1	7x7x30
6-6	069400	C-Sharped Snap Ring	2	#35
6-7	568488	Drive Shaft	1	
6-8	568489	Cover	1	
6-9	568655	Stay Comp.	2	
6-10	567172	Bolt	4	M6x14
6-11	082212	Bolt	4	M14x40
6-12	081354	Nut	4	M14
6-13	126796	Washer	4	M14

7. SSD600
CHEMICAL TANK



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
7-1	568490	Chemical Tank Ass'y	1	Incl.2-32
7-2	568491	Chemical Tank Comp.	1	
7-3	150772	Elbow	4	
7-4	150773	Packing	4	17x25x4
7-5	567074	Washer	4	17x30xt3
7-6	567075	Nut	4	G3/8
7-7	568632	Hydraulic Agitator	2	
7-8	567076	Nipple	2	
7-9	567077	Gasket	2	
7-10	567078	Lock Ring	2	
7-11	568494	Extension (G3/4XG1/2)	1	
7-12	568633	90°Fitting (G1/2)	2	
7-13	542709	Tee	1	1/2
7-14	189160	Nipple	2	R1/2xG1/2
7-15	567079	Extension	5	G1/2xG3/8
7-16	188601	Packing	3	12.5x18.5xt1.5
7-17	568634	Coupling (G11/4)	1	
7-18	568495	Fork Coupling (G11/4)	1	
7-19	568496	O-Ring	1	
7-20	568497	Tee Fitting	1	
7-21	568498	Hose Fitting	1	
7-22	568499	3-Way Ball Valves	1	
7-23	568500	Ball Valve	1	
7-24	568501	Fork	4	
7-25	568661	Basket Filter	1	
7-26	568502	Vinyl Hose	1	12x16x750L
7-27	568503	Vinyl Hose	1	12x16x690L
7-28	567220	Wire Clip	4	
7-29	568504	Mixer	1	
7-30	568505	Hose Comp.	1	13x19x1260L Incl.31,32
7-31	568638	O-Ring	2	
7-32	100691	Packing	2	13.5x18xt2

8. SSD600
WASHING TANK





Fig.7

Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
8-1	568506	Washing Tank Ass'y	1	Incl.2-4
8-2	568507	Washing Tank Comp.	1	
8-3	568514	Lid	1	
8-4	568639	Extension (G11/4)	1	
8-5	568515	Washing Tank Ass'y	1	Incl.6,7
8-6	568516	Washing Tank Comp.	1	
8-7	568514	Lid	1	
8-8	568519	Cock	1	
8-9	691334	Vinyl Hose	1	15x18x280L
8-10	659860	Hose Band	2	
8-11	568520	Bracket	1	
8-12	567035	Bolt	4	M8x25
8-13	567095	Flange Nut	4	M8
8-14	567173	Bolt	4	M8x20
8-15	127216	Washer	4	M8

9. SSD600
TANK FRAME



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
9-1	568521	Pipe Comp.	1	
9-2	568526	Pipe Comp.	1	
9-3	568530	Pipe Comp.	1	
9-4	568532	Pipe	1	
9-5	568533	Fook	1	M10
9-6	568534	Fook	1	M10
9-7	568535	Bracket	1	
9-8	194013	Clamp Band	1	
9-9	567065	Flange Bolt	14	M10x25
9-10	080317	Bolt	4	M10x55
9-11	567028	Washer	4	10.5x22xt3.2
9-12	567064	Flange Nut	20	M10
9-13	864249	Nylon Nut	4	M10
9-14	567093	Flange Bolt	1	M8x25
9-15	107581	Nylon Nut	1	M8
9-16	127216	Washer	1	M8

10. SSD600
FAN-1




Fig.12

Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
10-1	568553	Fan	1	
10-2	568554	Hublid	1	
10-3	568555	Wasehr	1	28.5x46xt3.2
10-4	568556	Washer	1	10.5x45xt4.5
10-5	568557	Key	1	8x7x65
10-6	568558	Fan Case Ass'y	1	Incl.7-14
10-7	568559	Ring	1	
10-8	568560	Inlet Air Distributor	1	
10-9	568561	Outlet Protection Grid	1	
10-10	092536	Bolt	8	M6x25
10-11	046365	Nylon Nut	8	M6
10-12	111848	Washer	8	6.5x20xt2
10-13	065005	Washer	8	M6
10-14	568604	Cover	1	
10-15	567065	Flange Bolt	1	M10x25
10-16	132092	Bolt	4	M8x30
10-17	117177	Nylon Nut	4	M8
10-18	065006	Washer	4	M8
10-19	092536	Bolt	2	M6x25

11. SSD600
FAN-2





Fig.10


Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
11-1	568551	Plate Ass'y	1	Incl.2-15
11-2	568606	Plate	1	
11-3	568607	Cover Comp.	1	
11-4	568611	Adjust Plate	1	
11-5	568613	Adjust Plate	1	
11-6	568614	Cover Comp.	1	
11-7	568617	Cover Comp.	1	
11-8	096048	Bolt	3	M8x20
11-9	081250	Nut	3	M8
11-10	065006	Washer	3	M8
11-11	088275	Wing Bolt	4	M6x20
11-12	092536	Bolt	4	M6x25
11-13	885612	Nut	8	M6
11-14	065005	Washer	8	M6
11-15	046365	Nylon Nut	4	M6
11-16	568605	Inlet Protection Glid	1	
11-17	568610	Collar	3	
11-18	194181	Bolt	3	M8x150x30
11-19	117177	Nylon Nut	3	M8
11-20	132092	Bolt	3	M8x30
11-21	015846	Spring Washer	3	M8
11-22	065006	Washer	12	M8
11-23	081250	Nut	3	M8
11-24	092536	Bolt	6	M6x25
11-25	046365	Nylon Nut	6	M6
11-26	111848	Washer	6	6.5x20xt2
11-27	065005	Washer	6	M6

12. SSD600
GEAR BOX




Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
12-1	568562	Gear Box Ass'y	1	Incl.2-45
12-2	568563	Bracket Comp.	1	
12-3	568568	Gear Box Ass'y	1	Incl.4-29
12-4	568569	Gear Case	1	
12-5	568571	Gear Case	1	
12-6	568573	Gear	1	
12-7	568574	Gear	1	
12-8	568575	Colalr	1	
12-9	568576	Shaft	1	
12-10	568577	Shaft	1	
12-11	568578	Shaft	1	
12-12	568579	Collar	2	
12-13	568580	Collar	1	
12-14	568581	Oil Seal	2	
12-15	568582	Gear	1	
12-16	568583	Shift Rod Comp.	1	
12-17	568586	Oil Seal	1	
12-18	568587	Coil Spring	1	
12-19	568588	Bearing	3	#6207
12-20	568589	Seal Washer	1	
12-21	568590	Bearing	3	#6205
12-22	568591	Plug Comp.	2	G1/4 Incl.23
12-23	568593	O-Ring	2	P12.5
12-24	568594	Knock Pin	2	8x20L
12-25	568595	Cap	1	
12-26	567035	Bolt	12	M8x25
12-27	567143	Nut	1	M10
12-28	567461	Bolt	1	M10x35
12-29	568596	Steel Ball	1	#8
12-30	568597	Lever Comp.	1	
12-31	568601	Stay	1	
12-32	568602	Stay	1	
12-33	568603	Collar	1	
12-34	080400	Bolt	2	M10x100x26
12-35	567062	Flange Bolt	2	M10x70
12-36	567064	Flange Nut	4	M10
12-37	567028	Washer	2	10.5x22xt3.2
12-38	567184	Bolt	1	M8x35
12-39	567095	Flange Nut	1	M8
12-40	567152	Washer	2	12.5x26xt2.3
12-41	132092	Bolt	2	M8x30
12-42	081250	Nut	2	M8
12-43	065006	Washer	2	M8
12-44	018081	Bolt	1	M6x40x16
12-45	567182	Nut	2	M6

12. SSD600
GEAR BOX




Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
12-46	689072	Bolt	4	M12x30
12-47	132117	Nut	4	M12

13. SSD600
NOZZLE




Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
13-1	568621	Spray Pipe Ass'y	1	Incl.2-30
13-2	568622	Spray Pipe Ass'y	1	Incl.3-5
13-3	568623	Pipe Comp.	1	
13-4	567529	Cap	1	G3/8
13-5	567530	Packing	2	15x20.5xt2
13-6	889025	2 Direction Nozzle Ass'y	6	Incl.7-16
13-7	691211	Body	6	
13-8	882112	Cap	12	
13-9	691212	Check Valve	6	
13-10	691213	Diaphragm Valve	6	
13-11	883783	Packing	6	
13-12	691214	Nozzle	6	
13-13	691215	Cap	6	
13-14	180540	Strainer	6	
13-15	691216	Packing	6	
13-16	691217	Nozzle	6	
13-17	567961	Body	7	
13-18	567962	Cover	7	
13-19	148710	Rubber Plate	7	16x24xt1.5
13-20	566055	O-Ring	6	P12
13-21	568650	O-Ring	7	P7
13-22	889026	Packing	1	
13-23	068998	Plate	1	18xt0.9
13-24	166721	Cap	1	
13-25	089961	Screw	14	ST3.5x24
13-26	568626	Plate	2	
13-27	568627	Plate	1	
13-28	104260	Extension	1	PF1/2xPF3/8
13-29	568625	Line Filter	1	
13-30	194273	Nipple	1	G1/2xG3/8
13-31	568628	Spray Pipe Ass'y	1	Incl.32-60
13-32	568629	Spray Pipe Ass'y	1	Incl.33-35
13-33	568623	Pipe Comp.	1	
13-34	567529	Cap	1	G3/8
13-35	567530	Packing	2	15x20.5xt2
13-36	889025	2 Direction Nozzle Ass'y	6	Incl.37-46
13-37	691211	Body	6	
13-38	882112	Cap	12	
13-39	691212	Check Valve	6	
13-40	691213	Diaphragm Valve	6	
13-41	883783	Packing	6	
13-42	691214	Nozzle	6	
13-43	691215	Cap	6	
13-44	180540	Strainer	6	
13-45	691216	Packing	6	

13. SSD600
NOZZLE



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
13-46	691217	Nozzle	6	
13-47	567961	Body	7	
13-48	567962	Cover	7	
13-49	148710	Rubber Plate	7	16x24xt1.5
13-50	566055	O-Ring	6	P12
13-51	568650	O-Ring	7	P7
13-52	889026	Packing	1	
13-53	068998	Plate	1	18xt0.9
13-54	166721	Cap	1	
13-55	089961	Screw	14	ST3.5x24
13-56	568626	Plate	2	
13-57	568627	Plate	1	
13-58	104260	Extension	1	PF1/2xPF3/8
13-59	568625	Line Filter	1	
13-60	194273	Nipple	1	G1/2xG3/8


14. SSD600
STRAINER



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
14-1	568449	Strainer Ass'y	1	Incl.2-6
14-2	568450	Suction Filter (#50)	1	
14-3	568451	Stay	1	
14-4	567035	Bolt	2	M8x25
14-5	567173	Bolt	3	M8x20
14-6	567095	Flange Nut	2	M8


15. SSD600

WATER DIVERSION



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
15-1	568453	Water Diversion Ass'y	1	Incl.2-31
15-2	568454	Water Diversion Ass'y	1	Incl.3-5
15-3	567087	Pressure Gauge	1	
15-4	863965	Divider	1	
15-5	863966	Plug	1	R1/2
15-6	567035	Bolt	2	M8x25
15-7	682393	Elbow	1	R1/2xG3/4
15-8	120835	Ball Cock	3	G3/8xR3/8
15-9	104260	Extension	1	PF1/2xPF3/8
15-10	116934	Pressure Regulator Valve Ass'y	1	Incl.11-30
15-11	105518	Cap	1	
15-12	118702	Knob	1	
15-13	088918	Cap Screw	1	M10x18
15-14	126195	Nut	1	M10
15-15	087484	Screw	1	M3xP0.5x6
15-16	088915	Cap Screw	1	M5x8
15-17	107912	Spring Seat	1	
15-18	103274	Spring	1	
15-19	107913	Spring Seat	1	
15-20	107914	Guide	1	
15-21	107915	Washer	1	22.6x26.7xt1
15-22	107916	Body	1	
15-23	107221	Spring	1	
15-24	106498	Valve Ball	1	5/32
15-25	117252	Sleeve	1	
15-26	013975	O-Ring	1	S24
15-27	105725	Piston Ass'y	1	
15-28	117251	Valve Seat	1	
15-29	011338	O-Ring	1	P18
15-30	020285	O-Ring	1	P24
15-31	066495	Nipple	1	PT1/2xPF3/4
15-32	567095	Flange Nut	4	M8
15-33	567172	Bolt	2	M6x14
15-34	568455	Pipe Comp.	1	
15-35	862459	U-Bolt	2	M8

16. SSD600
CHEMICAL PIPING



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
16-1	568536	Suction Hose Comp.	1	32x700L Incl.2,3
16-2	568643	O-Ring (G1)	2	
16-3	568644	O-Ring (G11/4)	2	
16-4	568537	Suction Hose Comp.	1	32x900L Incl.5,6
16-5	568643	O-Ring (G1)	1	
16-6	568644	O-Ring (G11/4)	1	
16-7	568538	Suction Hose Comp.	1	32x950L Incl.8,9
16-8	568643	O-Ring (G1)	1	
16-9	568644	O-Ring (G11/4)	1	
16-10	568539	Hose Comp.	1	10x16.5x3400L Incl.11
16-11	111569	Packing	2	9.5x15xt1.5
16-12	568540	Hose Comp.	1	10x16.5x3700L Incl.13
16-13	111569	Packing	2	9.5x15xt1.5
16-14	568542	Hose Comp.	1	10x16.5x1850L Incl.15
16-15	111569	Packing	2	9.5x15xt1.5
16-16	568544	Hose Comp.	1	10x16.5x2100L Incl.17
16-17	111569	Packing	2	9.5x15xt1.5
16-18	568546	Hose Comp.	1	10x16.5x390L Incl.19
16-19	111569	Packing	2	9.5x15xt1.5
16-20	568548	Hose Comp.	1	19x1Bx950L
16-21	568549	Hose Comp.	1	19x28x2550L Incl.22,23
16-22	568647	O-Ring (G3/4)	1	
16-23	188603	Packing	2	18.5x24xt2
16-24	567464	Band	5	
16-25	567585	Protect Hose	1	2x100L
16-26	568652	Protect Hose	10	2x50L
16-27	568362	Protect Hose	1	2x250L

17. SSD600
LABEL

1

MARUYAMA
AGRICULTURAL SPRAYER
MODEL: SSD600

2

CAUTION

1. READ THE INSTRUCTION MANUAL AND MEMORIZE HOW TO USE THE MACHINE AND USE IT.
2. READ THE INSTRUCTION MANUAL OF THE CHEMICAL, AND USE CORRECTLY.
3. DURING INSPECTION, ADJUSTMENT AND CLEANING, STOP THE ENGINE OF THE TRACTOR AND REMOVE THE KEY.

3

WARNING

1. PLEASE WEAR CLOTHES THAT FITS YOUR BODY. PREPARE PROTECTIVE CLOTHING, PROTECTIVE MASK, PROTECTIVE GLASSES, RUBBER GLOVES, WORKING SHOES(BOOTS)ETC AND WORK WITH SAFE CLOTHES.
2. DO NOT SUPPLY WATER DIRECTLY FROM DRINKING WATER SOURCES OR LAKES BREEDING LIVING THINGS.
3. MAKE A SPRAY PLAN SO THAT THERE IS NO SURPLUS CHEMICALS.
4. WHEN ATTACHING OR DETACHING THE SPRAYER, MAKE SURE THAT THE CHEMICAL TANK IS EMPTY.
5. DO NOT START MOVING SUDDENLY, SUDDEN TURNING, OR SUDDEN BRAKING. FALLING ACCIDE.NTS MAY BE INCURRED.


4

WARNING

WHEN ATTACH THE DRIVE SHAFT;
STOP THE ENGINE, REMOVE THE KEY,
APPLY THE PARKING BRAKE,
AND DISENGAGE THE PTO.

5

WARNING



DO NOT TOUCH
THE FAN.
GET INJURED

6

WARNING



DO NOT TOUCH
THE BELT.
GET INJURED.

7

PTO
540rpm


8

INSTRUCTIONS

TO STOP OR TERMINATE
THE SPRAYING OPERATION,
TURN THE PRESSURE
REGULATING DIAL ALL THE WAY
TO THE LEFT, LOWER THE PRESSURE
AND DISENGAGE THE PTO

9

COCK INSTRUCTIONS



14

MAXIMUM PRESSURE
2.0MPa (20bar)


15

LUBRICATION


16

OIN DRAIN PLUG

10




11




12

WASH STRAINER
AFTER OPERATION



13


GEAR BOX
OPERATION



17


MIN. INSERT


18





Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
17-1	568467	Label	3	SSD600
17-2	568468	Label	1	Caution
17-3	568469	Label	1	Warning
17-4	568470	Label	1	Warning
17-5	568471	Label	1	Warning
17-6	568472	Label	1	Warning
17-7	568473	Label	1	PTO 540rpm
17-8	568477	Label	1	Instructions
17-9	568478	Label	1	Instruction
17-10	568479	Label	1	Operation Nozzle
17-11	568480	Label	1	Pressure
17-12	568481	Label	3	Strainer
17-13	568653	Label	1	Instruction
17-14	568474	Label	1	Pressure
17-15	568475	Label	2	Lubrication
17-16	568476	Label	2	Oil Drain Plug
17-17	568482	Label	6	Min. Insert
17-18	567306	Label	1	Redzone


18. SSD600
ACCESSORIES











Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
18-1	568461	Instruction Manual	1	SSD600
18-2	568462	Installation Manual	1	SSD600
18-3	889023	Universal Joint	1	
18-4	568463	Bracket	2	
18-5	568464	Bracket	1	
18-6	567065	Flange Bolt	5	M10x25
18-7	567064	Flange Nut	5	M10